

Pioneering for You

## Wilo-Yonos MAXO/-D



ErP  
READY

APPLIES TO EUROPEAN DIRECTIVE FOR ENERGY RELATED PRODUCTS

2 172 447-Ed.02 / 2018-03-Wilo


# wilo

hu	Beépítési és üzemeltetési utasítás
pl	Instrukcja montażu i obsługi
cs	Návod k montáži a obsluze
ru	Инструкция по монтажу и эксплуатации
et	Paigaldus- ja kasutusjuhend
lv	Uzstādīšanas un ekspluatācijas instrukcija
lt	Montavimo ir eksploatavimo instrukcija
sk	Návod na montáž a obsluhu
sl	Navodila za vgradnjo in obratovanje
hr	Upute za ugradnju i uporabu
sr	Uputstvo za ugradnju i upotrebu
ro	Instrucțiuni de montaj și exploatare
bg	Инструкция за монтаж и експлоатация





[www.wilo.com/yonos-maxo/om](http://www.wilo.com/yonos-maxo/om)


HU	Beépítési és üzemeltetési utasítás	7
PL	Instrukcja montażu i obsługi	15
CS	Návod k montáži a obsluze	23
RU	Инструкция по монтажу и эксплуатации	30
ET	Paigaldus- ja kasutusjuhend	39
LV	Uzstādīšanas un ekspluatācijas instrukcija	46
LT	Montavimo ir eksploatavimo instrukcija	53
SK	Návod na montáž a obsluhu	60
SL	Navodila za vgradnjo in obratovanje	67
HR	Upute za ugradnju i uporabu	74
SR	Uputstvo za ugradnju i upotrebu	81
RO	Instrucțiuni de montaj și exploatare	88
BG	Инструкция за монтаж и експлоатация	96




→ 4.1




→ 2.2




→ 4.4






→ 5.4









→ 5.5




→ 5.5




→ 5.6






→ 6.3






→ 6.6



→ 6.6



→ 6.6



→ 7.2

